FREESTANDING WARDROBE – 1584
## INSTALLATION INSTRUCTIONS
01-07-24

code: 30170C

PANELS

LEFT SIDE PANEL: 1PC

RIGHT SIDE PANEL: 1PC

DIVIDER: 1PC

BACK PANEL: 2PCS

BOTTOM PANEL: 1PC

TOP PANEL: 1PC

FIXED SHELF: 2PCS

ADJUSTABLE SHELF: 2PCS

KICK BOARD: 2PCS

PARTS

CAMLOCK AND PIN
40 SETS

SHELF SUPPORT PINS
8 PCS

NAILS
(BACK PANEL)

NAILS
(BACK PANEL)

HANGING RAIL SCREW
(M4*16MM) 12 PCS
(OPTIONAL FITTING)

L-BRACKET SCREW
(M3.5*12MM) 4PCS

L-BRACKET SCREW
(M3.5*35MM) 4PCS

L-BRACKET
WALL PLUG 4PCS

L-BRACKET
2PCS

RAIL HOLDER
(OPTIONAL FITTING)

HANGING RAIL
(OPTIONAL FITTING)

SCREWDRIVER
1PC

1: LEFT SIDE PANEL

FRONT EDGE

x3

x3

x3

10

# 2: RIGHT SIDE PANEL

If your wardrobe contains drawers - place drawer runners as marked below using euro screws

x3

fix shelf
28th hole from base

FRONT EDGE

x3

x3

22nd hole from base

16th hole from base

10th hole from base

4th hole from base

3: DIVIDER

*If your wardrobe contains drawers - see step 2 for drawer runner positions*

4: BOTTOM PANEL

5: BOTTOM PANEL & KICK BOARDS

6: CAM LOCKS

7: TOP PANEL

8: BOTTOM PANEL

9: ASSEMBLY

White taped edge to this side

White taped edge to this side

## 10:

11: ASSEMBLE SIDE PANELS

Before assembly check the 2 shelf cam-locks line up (on side panels) level with the fixed shelves

12: NAIL BACK PANELS

NOTE: Make sure the wardrobe is positioned square before nailing on the backing panels.

13: FIT ADJUSTABLE SHELVES
*Using shelf support pins*

14: FIT L-BRACKETS x2
*Attach to wall for support*

SHORT SCREWS
M3.5*12MM

LONG SCREWS
M3.5*35MM

15: FIT HANGING RAIL BRACKETS
Optional fitting

250mm

MEDIUM SCREWS
M4*16MM

DRAWER INSTRUCTIONS

DRAWER FACING PANEL – 1 PC

DRAWER SIDE PANEL – 2 PCS

DRAWER BOTTOM BOARD – 1 PC

DRAWER BACKING PANEL – 1 PC

## DRAWER FITTINGS IDENTIFICATION

Cam-pins

Cam-locks

SCREW (M5*8MM)
Euro Screw for receiver runners

SCREW (M3.5*12MM)
for drawer runners

Receiver Runners

Drawer Runners

Tap cam-pins in place before tightening with screwdriver

Ensure wheels are facing the back of the drawer.
Fix drawer runners with screws to underside of drawer (do not screw from the side of the drawer)

Lower drawer into receiver runner at a downwards angle then glide the rest of the drawer in.
To engage the soft close feature, gently push the drawer fully inward.

INSTALLATION INSTRUCTIONS

Once you have completed the wardrobe build it's an easy six steps to finish with the installation your doors.

NOTE: Door hardware is supplied in the track pack.

1 Position the top door track flush with the front of the wardrobe and secure using the screws provided.

2 Position the bottom track ensuring it is placed 20mm in from the front of the wardrobe before securing.

3 Slip top of door into rear channel then set bottom onto the rear floor track. Repeat for the second door using front channel and track.

4 Lift the door and position its bottom wheels into their corresponding guide on the wardrobe floor.

5 Adjust the ride height of each door with a philips screwdriver (clockwise to increase height)

6 To control movement, peel adhesive & place the brake into each track where you want the wheels on top of the doors to remain stationary.