

# INSTALLATION INSTRUCTIONS

ASPIRING SERIES & TASMAN SERIES WARDROBES

wardrobes  
online




CAM PINS



CAM LOCKS




SHELF SUPPORT




ECONO BRACKETS



WALL PLUG



SCREWDRIVER




SCREW LARGE



SCREW SMALL

These parts are  
located in the  
Shelf Pack



**WATCH HOW  
TO INSTALL  
YOUR  
WARDROBE,  
VIEW INSTALL  
VIDEOS ON  
OUR WEBSITE  
SCAN QR >**




**Be sure to check ALL boxes, as fixings can be found across all boxes, not just this one!**




1. Lay out one of the side panels and screw **Cam Pins** at the 3 fixed shelf positions and the back-cleat support. Repeat the same on the second panel, ensuring the shelf positions match.

Refer to **Diagram A** on the last page for shelf positions.  
And back-cleat support position identified (pic shown)



2. For drawer towers: install the receiving drawer runners (refer Diagram A) using the Euro Screws pictured (parts included in the drawer box). Wheels to the front of the tower, screw at both the front and back of the runner. Second hole in from the wheel at the front as shown. Repeat on the second panel, ensure drawer runner positions match. Refer to **Diagram A** for drawer runner positions.



3. There are 3x fixed shelves, and 1x back-cleat. Insert the **Cam Locks** into the fixed shelves, and back-cleat, arrow facing outwards. If they are a tight fit, gently tap them in place with a mallet.



4. On one of the side panels, slot the top shelf into the first fixed shelf position. Ensure the white edge of the shelf is at the front of the tower, and that the cams are facing the ceiling at the top of the tower. Repeat with the back-cleat ensuring cams are facing the back of the tower so they won't be visible. Once the shelf and back-cleat is in place, tighten the cams with the screwdriver. Be careful not to overtighten. Repeat with the middle and lowest fixed shelf, but ensure the cams are facing the floor.






5. Once the drawer runners have been installed on both side panels, lower the second side panel into place where **Cam Pins** meet with **Cam Locks**. Tighten **Cam Locks** with screwdriver.




6. As the tower is currently on its side, turn the tower onto its back. From this position carefully stand the tower up. **IMPORTANT: do not stand the tower up from its side. The tower will be unstable until it has been secured to the back wall of the wardrobe – refer Step**



7. Once your tower is upright, carefully position the tower in place within your wardrobe. For drawers to operate correctly, make sure the wardrobe tower is on a level surface and square to the back wall. If the floor is not level then floor packers may be required (not included). Using a level, ensure the tower is standing square and fix the tower to the back wall using the **Econo Brackets** (pictured). We recommend installing one on top of the tower, and the other bracket under the middle-fixed-shelf (this will be hidden if drawers are being used). Where possible, fix brackets into studs, or if studs are not available use the Wall Plugs provided. Use a 5mm drill bit. Use **Small Screws** to attach bracket to tower, and **Large Screws** to attach bracket to wall.



8. **Drawers:** "Before placing drawers into the unit, make sure the drawer receiver-runners (fixed to the unit) are fully extended by pulling the soft-close section all the way out as shown ->"



9. Install drawers by angling the drawer (as shown) and lower and level the drawer as you slide it in. To engage the soft close feature, gently push the drawer fully inward. Refer **Drawer Assembly** instructions.




**Adjustable Shelves:** insert at your desired heights using the **Shelf Supports**.

**Gable/End Panel (sold separately):** IF you have purchased separately, secure to the back wall using the additional Econo brackets provided into studs, 2 per panel (if studs are not available use the wall plugs provided). If using the Gable/End Panel at an open end (not against a side wall), install the Econo Brackets into studs either side of the Gable. Extra fixings may be required to ensure Gable is fixed in place.




## Diagram A

Tower with 1-5 Standard Drawers



Tower with 2x Standard & 2x Jumbo Drawers



If you have a shelf tower, you can choose where to install your adjustable shelves between the top, middle and lowest fixed shelves.



# INSTALLATION INSTRUCTIONS

## TOP SHELF

wardrobes  
online





**WATCH THE VID**

**SCAN QR >**

### PANEL & COMPONENT IDENTIFICATION


SHELF (1200 MM)




LEFT AND RIGHT SHELF  
BRACKETS



TOWER SCREWS





WALL SCREWS




WALL PLUGS

Mount a shelf bracket on the side of your tower using the shorter screws – install bracket 2mm down from the top edge of the tower, this will create a seamless finish with the shelf sitting flush with the tower. If you are mounting the shelf bracket to the wall then use the longer screws and wall plugs. Use a Level during this step.



### Suggestion:

If you wish to adjust the width of a shelf, first measure and mark it. Place a strip of masking tape on both sides of the area you wish to cut, re-mark the required length and cut through the tape. When completed remove the tape to reveal a nice clean cut. We recommend a min 8pt saw for melamine.



**DETAILED INSTRUCTIONS OVER PAGE...**




1. Shelf Brackets are marked "L" and "R" for left/right and have a closed rim at the front and an open end at the back which is designed so the front rim stops the shelf falling forwards.

After your assembled tower has been secured to your wall, measure the width of space the top shelf is to be installed. As the shelf brackets are 6mm deep each, you will need to deduct **12mm** from this measurement to get your final top shelf length.

**Example:** If your wall-to-wall measurement is 1000mm wide, then you need to cut your top shelf 988mm wide.



2. Mark on your shelf where you need to cut. Tip: Use masking tape along the cut line. This will give the melamine board a cleaner finished edge. Cut the shelf using a saw. We recommend a minimum of an 8pt saw to cut melamine.



3. Some wardrobe towers have pre-drilled pilot holes for top shelf brackets – if these are available then screw bracket into place using 16mm screws. If there are no pilot holes present, the top shelf bracket needs to be installed 2mm down from the top edge of the tower in order to create a seamless finish with the shelf sitting flush with the tower. Place the shelf in position with the shelf bracket, and pencil mark the position of the opposite bracket (use a spirit level to ensure your shelf is level). Use the shelf bracket as a template to mark out the holes for the screws.





4. Install wall plugs where required (ie gibbed walls where studs are not available), and screw shelf bracket onto wall.

Lastly, Insert shelf into bracket.



5. **For Walk-In wardrobes using a corner**

For walk-in wardrobes where top shelves meet adjacently in a corner, you will require a **Corner Shelf Bracket**. Apply a **4mm** deduction where a corner shelf bracket is to be used. And a **6mm** deduction where a shelf bracket is to be used.

Once your top shelf is installed from the tower-to-wall (ie 'Shelf A' in example), slot the **Corner Shelf Bracket** on, push from underneath so it's flush with the underside of the top shelf and screw in place.


Next, measure from the **Corner Shelf Bracket** to the side of the tower on Wall B and cut shelf accordingly. Holding 'Shelf B' on an angle, slot into the Corner Shelf Bracket and lower down into the opposite Shelf Bracket.

**Example: Walk-in wardrobe 1600mm x 1300mm - Layout as Pictured**

**Wall A:** 1000mm tower-to-wall measurement, deduct 12mm for 2x shelf brackets. Cut shelf 988mm ('Shelf A').

**Wall B:** deduct measurement of adjacent shelf depending on which system you order will determine the depth of the shelf usually 300mm or 400mm. In this case our example is using a 400mm deep shelf.  $700 - 400 = 300$ mm. Then deduct the shelf bracket (-6mm) and the Corner Shelf Bracket (-4mm). Cut shelf 290mm ('Shelf B').

**IMPORTANT FOR WALK-INS: WHERE WE SAY "FITS UP TO 2400mm" – THIS CAN TAKE INTO ACCOUNT THE USE OF THE ADJACENT SHELF USING 400MM OF THAT WALL SPACE. IE – SHELF B WHEN JOINED ADJACENTLY WITH THE SHELF A, IT IS ABLE TO FIT A WALL THAT IS LONGER. PLAN WHERE YOU WILL INSTALL YOUR SHELVES BEFORE YOU CUT!**





# INSTALLATION INSTRUCTIONS

## HANGING RAILS

wardrobes  
online

WATCH HOW  
TO INSTALL  
YOUR  
WARDROBE

SCAN QR >



1. For Top Height Rail: Measure 250mm from the back of the tower/wardrobe panel. And 50mm down from the top edge of the tower.  
Screw the Rail End Bracket into the wall or tower: Use short screws to fix bracket to a tower.  
Next install the opposing hanging rail using a measuring tape and level to ensure it is installed at the same height.  
Use longer screws to fix bracket into a wall. Install wall plugs where required for a stronger install into gib.  
For Mid Height Rail: Measure 250mm from the back of the tower/wardrobe panel.  
From that mark, measure 1000mm down from the top-height-rail.



2. Measure the length between the installed rail brackets to get your rail length.  
\*Tip allow 2.5mm for each Rail End Bracket, so a 600mm wide gap between two walls you would cut the rail at 595mm.



3. Mark on rail your measured length and cut the rail using a hacksaw.  
Once cut, slot rail into rail brackets.

***Note: because floors are sometimes not level we recommend you check heights and levels as you proceed through the installation process***

